


anex ozy

MAINTENANCE

MANUAL





01	Included in set	3
02	Unfolding	4
03	Folding	5
04	Adjusting legs on ground	6
05	Attachment of adapters	7
06	Height regulation with adapters	7
07	Removal of adapters	8
08	Newborn seat assembly	9
09	Newborn seat attachment and removal	11
10	Newborn seat angle adjustment	12
11	Newborn seat safety belts	13
12	Toys assembly	15
13	Toys holder attachment	16
14	High chair assembly	16
15	High chair attachment and removal	18
16	High chair safety belts	19
17	High chair tray adjustment	21
18	High chair angle adjustment	23
19	Activity tower bumper assembly	23
20	Activity tower bumper attachment and removal	24
21	Activity tower usage	25
22	Storage	26

Included in set





1. Main base	2. Height adapters L&R	3. Newborn seat adapters L&R	4. Toys holder	5. Newborn seat upper tube	6. Newborn seat lower tube	7. Newborn seat toys	8. Newborn seat soft goods
9. Newborn seat insert	10. High chair soft goods	11. High chair seat	12. High chair tray	13. High chair tray insert	14. Activity tower barrier adapters L&R	15. Activity tower barrier	16. Activity tower bumper


Unfolding



Folding




Adjusting legs on ground




05

Attachment of adapters




06





Height regulation with adapters





Removal of adapters




Newborn seat assembly







Newborn seat attachment and removal






Newborn seat angle adjustment




Newborn seat safety belts







Toys assembly







Toys holder assembly




High chair assembly











High chair attachment and removal







High chair safety belts








High chair tray adjustment












High chair angle adjustment




Activity tower bumper assembly






Activity tower bumper attachment and removal



Activity tower usage



Storage



EN 12790-1:2023

EN 14988:2017+A2:2024

EN 14183:2003

Check for the most recent manuals on our website:
anexbaby.com

The information is subject to change without notice.
Anex shall not be liable for technical errors or omissions
contained in this manual. The purchased product may
differ from the product as described in this manual.

AVALEX PTE. LTD.
114 Lavender Street, #08-58/59
CT Hub 2, Singapore 338729
+65 62215096
office@anexbaby.com

Importer and Economic Operator in the EU:
IDEO GROUP SPOLKA Z O. O.
Address: Al. Solidarnosci 117 lok. 207,
00-140 Warsaw, Poland
office@anexbaby.com