

doona™

Liki Trike



User Guide


S1

S3

S5

產品名稱：多娜兒童三輪車
型號：樂奇

English
Spanish
Portuguese
Polish
Romanian
Chinese



50500713

Max load – 20kg / 44lbs • Age limit – 10-36 months



Please register your product

ATTENTION!

In order to ensure your Child's safety, please register your product at www.doona.com/register

If you do not register your product we will not be able to communicate critical safety information to you if needed.

SCAN []



This manual contains important information regarding the correct use, safety features, and maintenance instructions for your trike.

Read this manual carefully before use and keep it in an accessible place for future reference.

In case of questions or issues, please contact your local distributor or contact us through our website: www.doona.com

If you have any further questions regarding this trike, please feel free to contact us at:
www.doona.com/international-partners

Warnings of use

- **ADULT SUPERVISION REQUIRED.** NEVER leave child unattended.
- **WARNING! TO AVOID SERIOUS INJURY:** Continuous adult supervision is required; NEVER use near motor vehicles, NEVER use near streets, swimming pools, hills, steps, or sloped driveways. ALWAYS wear shoes when using the product. NEVER allow more than one rider.
- **WARNING!** Not to be used by children over the age of 36 months.
- **WARNING!** Not to be used by children over the weight of 20kg / 44lbs.
- **WARNING!** We recommend the use of suitable protective clothing and a safety helmet.
- **WARNING!** Riders should always wear a properly fitted helmet that complies with U.S. Consumer Products Safety Commission (CPSC) Standard 16 CFR 1203.
- **WARNING!** Instruct children about correct use of the product and draw their attention to possible dangers.
- **WARNING!** This product does not have lights or reflecting safety marks. It is not safe for use in the dark.
- **WARNING!** Small parts choking hazard. Adult assembly required. When replacing Backrest tighten all fasteners.
- This product is designed only for private, residential use.
- This product cannot be used for commercial or public use.
- This product is not suitable for jogging, skating, or any high-speed use.
- Keep away from fire.
- Tipping hazard – DO NOT load weight or hang bags on parent control bar, for storage - use the designated accessory hook with LIKI accessory only.
-Max load on the accessory hook: 2.5kg / 5.5lbs.
- **NEVER** use non-regulated parts and accessories on LIKI. Non-regulated parts and accessories may disturb the performance of LIKI in case of sharp turn or a sudden stop.
- When not in use, ENSURE that the product is out of your child's reach to avoid injuries.
- When product is used with mounted backrest – ALWAYS properly restrain your child with restraint system.
- ENSURE removal of all accessories before folding the product.

- NEVER use the product without a backrest.
- ENSURE all mechanism locks are properly locked before every use.
- NEVER tilt or lift the product when a child is seated.
- NEVER try to go up and down stairs with a child seated in the product.
- Keep hands away from moving parts at all times.
- ENSURE adjusting the product's mode according to the child's age and developmental level.
- ENSURE Steering and Pedal Locks are engaged before child rides in Mode 3 (24-30 months).
- ENSURE moving the pedals from footrest position to pedal position before moving from mode 2 to mode 3 (24-30 months or 30 lbs/13 kg).
- Remove high backrest before allowing child to use in mode 4 (30-36 months).
- NEVER use without push handle until child is ready to safely ride product on their own.
- Assembly must be done by an adult in order to ensure all parts are properly connected.
- After removing the pushing handle, the pedal lock button shall be engaged to ensure the pedal would work properly and safely.
- Please instruct your child how to use the product correctly and draw attention to possible sources of danger. The product shall be used by a child with enough skill in order to avoid falls or collisions causing injury to the user or third parties.


Handling, maintenance, and care

- Check for defects or critical wear before every use. If the products has suffered from a crash/impact/any other damage, it should not be used. If any worn or defective parts are spotted, please contact your local distributor or contact us at www.doona.com for further instructions.
- Lubricate moving parts with few drops of PTFE lubricant periodically.
- The product is NOT intended for use on/through sand/ sea/ dust/ mud/ leaves/ grassy surfaces.
- Store in a dry environment for better protection. For best results, store in its designated storage bag. NEVER store in a humid or wet environment.
- NEVER clean with high pressure water / air cleaner. NEVER use soap, detergents, or chemical solutions.
- Clean the product using only room temperature water, then carefully wipe the whole product with a soft cloth.
- Harness and textile care instructions: please refer to the instructions on the attached care label.
- Keep product away from corrosive materials.

Technical information

- Product dimensions – 339 / 610 / 251mm | 13.3 / 24.0 / 9.8 inches
- Product weight – 6.7Kg / 14.7lbs
- Max load – 20kg / 44lbs
- Age limit – 10-36 months

Overview / Resumen / Visão geral / Budowa rowerka /
Prezentare / 概覽



1 Handle bar
Manillar
Barra de Controle
Kierownica
Ghidon
車把

2 Handle bar fold button
Barra de Controle
Botão de dobra na barra
Przycisk składania kierownicy
Buton pliere manere
車把摺疊按鈕

3 Steering lock button
Botón de bloqueo del volante
Botão de travamento
Przycisk blokady kierownicy
Sistem blocare ghidon
轉向鎖按鈕

4 Body fold button
Botón de plegar el cuerpo
Botón de plegar el cuerpo
Przycisk składania korpusu
Buton pliere tricicleta
車身摺疊按鈕

5 Pedal
Pedal
Pedal
Pedal
Pedala
踏板

6 Pedal release button
Botón liberador de pedal
Botón liberador de pedal
Przycisk zwolnienia pedału
Buton delasare pedala
踏板釋放按鈕

7 Front wheel
Rueda delantera
Roda dianteira
Przednie koło
Roata fata
前輪

8 Parent control bar
Barra de control paterno
Barra de controle parental
Drążek kontroli rodzicielskiej
Maner parinte
家長控制杆

9 Canopy
Capota
Dossel
Daszek
Capotina
遮蓬

10 Canopy connector
Conector de la capota
Conector do dossel
Łącznik daszka
Conector capotina
遮蓬連接器

11 Backrest
Respaldo
Encosto
Oparcie dla pleców
Spatar
靠背

12 Armrest
Apoyabrazos
Apoio de braço
Podłokietnik
Coliera
扶手

13 Backrest connector
Conector del respaldo
Conector do encosto
Łącznik oparcia dla pleców
Conector spatar
靠背連接器

14 Rear wheel
Rueda trasera
Roda trasera
Tylnie koło
Roata spate
后輪

15 Pedal connector
Conector del pedal
Conector do pedal
Łącznik pedała
Conector pentru pedala
踏板連接器

16 Pedal clutch
Embrague del pedal
Embreagem de pedal
Sprzęgło pedału
Pedala ambreiaj
脚踏離合器

17 Accessories hook
Gancho de accesorios
Gancho de acessórios
Hak dla akcesoriów
Carlig pentru accesorii
附件掛鉤

18 Backrest folding lever
Palanca de plegado del respaldo
Alavanca do encosto dobrável
Dźwignia składania oparcia
Sistem pliere spatat
靠背摺疊杆

19 Parent handle connector
Conector para la barra paterna
Conector da alavanca parental
Złącze uchwytu dla rodziców
Conector maner parinte
家長扶手連接器

20 Personalized name plate
Placa personalizada con nombre
Placa personalizada com nome
Spersonalizowana tablica imienna
Placuta de identificare
個性化名牌

21 Brake pedal
Pedal de freno
Pedal de freio
Pedal hamulca
Frana de picior
制動踏板


22 Lower backrest
Respaldo inferior
Encosto inferior
Niższe oparcie
Spatar inferior
椅背

23 Safety harness
Arnés de seguridad
Arnês de segurança
Pasy bezpieczeństwa
Hamur de siguranță
安全帶

Modes of use / Modos de uso / Modos de utilização / Tryby użycia / 使用模式


1 10-18 months / meses / mesi / mėsių / 個月

- | | | |
|---|--|--|
| <ul style="list-style-type: none"> • Backrest • Canopy • Armrest • Parent control bar • Footrest • Safety harness | <ul style="list-style-type: none"> • Respaldo • Capota • Barra de seguridad • Barra de control paterno • Reposapiés • Arnés de seguridad | <ul style="list-style-type: none"> • Encosto • Dossel • Barra de segurança • Barra de controle parental • Apoio para os pés • Cinto de segurança |
| <ul style="list-style-type: none"> • Oparcie dla pleców • Daszek • Podłokietnik • Drążek kontroli rodzicielskiej • Podnóżek • Pasy bezpieczeństwa | <ul style="list-style-type: none"> • Spatar • Capotina • Cotiera • Maner parinte • Pedala de odihna • Hamuri de siguranta | <ul style="list-style-type: none"> • 靠背 • 遮蓬 • 扶手 • 家長控制杆 • 腳攔板 |




2 18-24 months / meses / mesi / mėsių / 個月

- | | | |
|---|--|--|
| <ul style="list-style-type: none"> • Backrest • Parent control bar • Footrest • Safety harness | <ul style="list-style-type: none"> • Respaldo • Barra de control paterno • Reposapiés • Arnés de seguridad | <ul style="list-style-type: none"> • Encosto • Barra de controle parental • Apoio para os pés • Cinto de segurança |
| <ul style="list-style-type: none"> • Oparcie dla pleców • Drążek kontroli rodzicielskiej • Podnóżek • Pasy bezpieczeństwa | <ul style="list-style-type: none"> • Spatar • Maner parinte • Pedala de odihna • Hamuri de siguranta | <ul style="list-style-type: none"> • 靠背 • 家長控制杆 • 腳攔板 |




3 24-30 months / meses / mesi / mėsių / 個月

- | | | |
|---|---|---|
| <ul style="list-style-type: none"> • Pedals • Parent control bar • Backrest • Safety harness | <ul style="list-style-type: none"> • Pedales • Barra de control paterno • Respaldo • Arnés de seguridad | <ul style="list-style-type: none"> • Pedais • Barra de controle parental • Encosto • Cinto de segurança |
| <ul style="list-style-type: none"> • Pedaty • Drążek kontroli rodzicielskiej • Oparcie dla pleców • Pasy bezpieczeństwa | <ul style="list-style-type: none"> • Pedale • Maner parinte • Spatar • Hamuri de siguranta | <ul style="list-style-type: none"> • 踏板 • 家長控制杆 • 靠背 |




4 30-36 months / meses / mesi / mėsių / 個月

- | | | |
|--|--|--|
| <ul style="list-style-type: none"> • Pedals • Lower backrest | <ul style="list-style-type: none"> • Pedales • Respaldo inferior | <ul style="list-style-type: none"> • Pedais • Encosto inferior |
| <ul style="list-style-type: none"> • Pedaty • Niższe oparcie | <ul style="list-style-type: none"> • Pedale • Spatar inferior | <ul style="list-style-type: none"> • 踏板 • 放低靠背 |




* Product features might vary by models / Le caratteristiche del prodotto possono variare a seconda del modello / As instruções, podem variar de acordo com os modelos / Cechy produktu mogą się różnić w zależności od modelu / Caracteristicile produsului pot varia în funcție de model


Unfolding / Despliegue / Desdobrando / Rozkładanie / Depliere / 展開




Folding / Plegable / Dobrando / Składanie / Pliere / 摺疊




Armrest removal / Remoción de apoyabrazos / Remoção do braço / Usunięcie Podłokietnika / Detasare cotiera / 扶手擦除



Backrest recline / Reclinación del respaldo / Reclinador do encosto / Pochylenie oparcia / Inclinare spatar / 傾斜靠背




Replacing backrest / Reemplazar el respaldo / Substituir encosto / Wymiana oparcia / Inlocuire spatar / 靠背位置復位




Safety features / Características de seguridad / Procedimentos de segurança / Funkcje bezpieczeństwa / Siguranta / 安全功能


- 1**
- Brake pedal
 - Pedal de freno
 - Pedal de freio
 - Pedal hamulca
 - Frana de picior
 - 制動踏板




- 2**
- Pedal Lock button
 - Botón de inhibición del pedaleo.
 - Przycisk blokady pedału
 - Botão de bloqueio de pedal
 - Buton blocare pedale
 - 安全帶



- 3**
- Safety harness
 - Arnés de seguridad
 - Cinto de segurança
 - Pasy bezpieczeństwa
 - Centuri de siguranta
 - 安全帶







- 4**
- Steering lock button
 - Botón de bloqueo del volante
 - Botão de travamento
 - Przycisk blokady kierownicy
 - Sistem blocare ghidon
 - 轉向鎖按鈕








Parent control bar / Barra de control paterno / Barra de controle parental / Drążek kontroli rodzicielskiej / Maner parinte / 家長控制杆

- Assembly
- Montaje
- Montagem
- Montaj
- Montaj
- 組裝



Parent control bar / Barra de control paterno / Barra de controle parental / Drążek kontroli rodzicielskiej / Maner parinte / 家長控制杆


- Disassembly
- Desmontaje
- Desmontagem
- Demontaž
- Demontare
- 拆卸




Pedal / Pedal / Pedal / Pedal / Pedale / 踏板

1

- Footrest mode
- Modo reposapiés
- Modo de apoio para o pé
- Tryb podnóżka
- Mod pedalare
- 擱腳板模式




- Release
- Liberar
- Liberar
- Zwolnić
- Deblocare
- 釋放




2

- Pedal mode
- Modo de pedal
- Modo pedal
- Tryb pedałowania
- Mod odihna
- 踏板模式




- Release
- Liberar
- Liberar
- Zwolnić
- Deblocare
- 釋放





Storage bag / bolsa de almacenamiento / 儲物袋 Saco de armazenamento / Pokrowiec / Pung de depozitare


*Storage bag not included with all models
并非所有型号的Liki都
含儲物袋



Canopy / Capota / Dossel / Daszek / Capotina / 遮蓬



Textile removal / Eliminación texti / Remoção do tecido / Usunięcie materiału / Detasare parte textilă / 織物移除



**Safety harness installation / Instalar arnes de seguridad /
Instalar o arnês de segurança / Montaż pasów bezpieczeństwa /
Instalati centurile de siguranta / 安全帶安裝**

**Safety harness removal / Retirada del arnés de seguridad /
Remover o arnês de segurança / Usunięcie pasów
bezpieczeństwa / Scoatere centuri de siguranta / 安全帶拆卸**

